

RAPID PATCH™

Fast Setting, Non-Sagging,
Patching Material



PRODUCT DESCRIPTION

RapidPatch is a one-component, fast-setting, polymer-modified, fiber-reinforced, cement-based, non-sagging, patching material for Dryvit systems. The product is supplied in 1 gal (3.78 L) plastic pails and, when mixed with water at the job site, produces an easily applied, high performance, non-shrinking, patching material.

USES

RapidPatch is an exceptional patching material specially engineered to patch holes in an existing EIF system up to a maximum depth of 1 in (25 mm).

PROPERTIES

Working Time: After mixing, the working time of RapidPatch is 20-30 minutes, depending on ambient temperature.

Drying Time: RapidPatch may be ready for finish coat application in 60 minutes at 70 °F (21 °C), 55% R.H. Lower temperatures and higher humidity will extend the curing time.

Water Vapor Transmission: (ASTM E 96) – RapidPatch is permeable to water vapor.

Bond Strength: (ASTM C 297 Modified) – Bond strength between RapidPatch and expanded polystyrene insulation board exceeds the tensile strength 20.0 psi (138 kPa) of the expanded polystyrene insulation board when test samples are cured for 14 days. The bond strength is 17.2 psi (119 kPa) with an adhesive failure of 19% when test samples are cured for 14 days and soaked in water for 24 hours.

SURFACE PREPARATION

Surface must not be below 40 °F (4 °C) or painted and must be clean, dry, structurally sound and free of efflorescence, grease, oil, form release agents and curing compounds.

MIXING

One pail of RapidPatch will produce approximately 1 gal (3.78 L) of RapidPatch mixture. RapidPatch may be mixed by mechanical or manual means. RapidPatch should be mixed to a thick consistency such that it does not sag on the wall.

Mechanical mixing: To a clean 1 gal (3.78 L) pail, add 0.8-1.0 qt (0.77-0.95 L) of clean potable water. Add the RapidPatch slowly while constantly mixing with 2 in (50 mm) ribbon type mud mixer (such as Marshalltown® Part No. RM771) at 450-500 rpm. Thoroughly mix until uniformly wetted, adjusting consistency with a small amount of water or RapidPatch. Let set for 4-5 minutes. Retemper, adding a small amount of water if necessary. Material must be free of lumps before using.

Manual mixing: Add the measured small quantities of RapidPatch to the proper amount of clean portable water in a clean container and mix with a margin trowel. Mix for 3-5 minutes and let it set for 4-5 minutes. Re-mix to break the set for 1 minute and add a small amount of water if necessary. The pot life is 20-30 minutes depending on ambient temperature.

DS 458

COVERAGE

230 in³ (3770 cm³) per 1 gal (3.78 L) pail. This fills approximately 25 holes measuring 3 in x 3 in x 1 in (76 mm x 76 mm x 25 mm) in dimension.

STORAGE

RapidPatch must be stored at a minimum of 40 °F (4 °C) and a maximum of 100 °F (38 °C) protected from weather and out of direct sunlight. If RapidPatch is warm or hot, its pot life will be greatly reduced.

The shelf life is 1 year from date of manufacture when properly stored in unopened pails.



RAPID PATCH™

Fast Setting, Non-Sagging,
Patching Material



APPLICATION

1. With a sharp utility knife, cut through and remove the lamina, exposing a neat uniform-sized area of insulation larger than the damaged area. Use a disk grinder or belt sander to remove the finish, exposing the reinforced base coat approximately 3 in (76 mm) around the damage area. Use a 20 grit aluminum oxide disk or belt.
2. Cut out the loose, exposed foam and reveal fresh foam. Cutting off the foam all the way to substrate is not recommended. When foam in the damaged area is well bound to substrate, care must be taken to expose as little of the substrate as possible and prevent rupturing the surface of the substrate. The area to be patched must be at least 3/4 in (19.0 mm) and 1 in (25 mm) in depth. Deeper patches should be filled with a piece of EPS so the patch is within this range. The EPS can be adhered to the substrate using RapidPatch material.
3. Precisely mask the surrounding finish with masking tape.
4. Apply RapidPatch mixture to the damaged area with a margin trowel to a depth of approximately 1/8 in (3.2 mm) below the existing base coat surface. Also add a small amount of material onto the exposed base coat surrounding the patch. Place a piece of Detail Mesh over the wet RapidPatch overlapping the existing base coat a minimum of 1 in (25 mm). Add additional RapidPatch material to completely fill the damaged area, cover the mesh and feather onto the surrounding base coat. If the patching material in the damaged area appears loose initially, wait until it stiffens up and level off any imperfections with additional RapidPatch mixture as needed.
5. When the patching material in the damaged area is stiff enough, use a clean, damp margin trowel, to smooth out the surface. This may be repeated until a satisfactory appearance is achieved. The trowel must be clean and damp prior to each smoothing.
6. Let RapidPatch set for at least 60 minutes, depending on ambient conditions.
7. If necessary, again, precisely mask the surrounding existing finish with masking tape.
8. Install the new finish over the patched area and texture to match the surrounding finish. Do not sand the patched area prior to finish application.

Note: Because RapidPatch is specifically designed to compensate for drying shrinkage, it may be used to repair damaged areas up to 3 in x 3 in x 1 in (76 mm x 76 mm x 25 mm).

Job Conditions: Air and surface temperature for application of RapidPatch must be 40 °F (4 °C) or higher and must remain so until RapidPatch is cured. When ambient temperature is above 75 °F (24 °C), water used for mixing should be chilled to a temperature less than 75 °F (24 °C).

Temporary Protection: Shall be provided at all times until patching material, finish and permanent flashings, sealants, etc. are completed to protect the wall from weather and other damage.

DS 458

CAUTIONS & LIMITATIONS

- Clean potable water may be added to adjust workability. Do not overwater.
- Avoid working in direct sunlight and keep mixed RapidPatch in the shade. Always work on the shady side of the wall or protect the area with appropriate shading material.
- Wear protective eyewear and clothing since the product does contain cement, which can irritate.

CLEAN UP

Clean tools with water while RapidPatch mixture is still wet.

TECHNICAL AND FIELD SERVICES

Available upon request.

Information contained in this product sheet conforms to the standard detail recommendations and specifications for the installation of Dryvit Systems, Inc. products as of the date of publication of this document and is presented in good faith. Dryvit Systems, Inc. assumes no liability, expressed or implied, as to the architecture, engineering or workmanship of any project. To ensure that you are using the latest, most complete information, contact Dryvit Systems, Inc.

For more information on [Dryvit Systems](#) or [Continuous Insulation](#), visit these links.

Printed in USA. Issued 10-04-16
©Dryvit Systems, Inc. 2002



Dryvit Systems, Inc.
One Energy Way | West Warwick, RI 02893
(800) 556-7752 | www.dryvit.com