



NOTE:

- 1. ALTERNATE FASTENERS AT EACH STUD.
- 2. STAGGER VERTICAL JOINTS AT ALL INSIDE AND OUTSIDE CORNERS.
- 3. INSTALL INSULATION BOARD IN RUNNING BOND PATTERN.
- 4. TIGHTLY BUTT ALL INSULATION BOARDS.

- 5. INSTALL THREE FASTENERS PER 2 FT (610 MM) BY 4 FT (1219 MM) INSULATION BOARD IMMEDIATELY FOLLOWING BOARD PLACEMENT WHILE ADHESIVE IS STILL WET.

- 6. FOR ADDITIONAL BACKSTOP NT DETAILS, REFER TO DRYVIT PUBLICATION DS840.

- 7. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.

- 8. THE ONLY WRB TO BE USED WITH BACKSTOP® FLASH AND FILL IS BACKSTOP® NTX™.

The architecture, engineering, and design of the project using the Dryvit and Tremco products are the responsibility of the project's design professional. All products and systems must comply with local building codes and standards. This detail is for general information and guidance only and Dryvit and Tremco specifically disclaims any liability for the use of this detail. The project design professional determines, in its sole discretion, whether this detail or a functionally equivalent detail is best suited for the project. This detail is subject to change without notice. Contact Dryvit and Tremco to ensure you have the most recent version.

Outsulation® X™ System®



Dryvit Technical Support: 800-556-7752

Detail: AWRB Application and Fastening Pattern

Drawn by: KAB

Checked by: CB

Scale: NTS

Date: 2/2022

File Name:

OX 2



Construction Products Group

www.tremcocpg.com