



## NewBrick®

## Expansion Joint At Floor Line

**NOTE:**

1. OUTSULATION RMD SYSTEM SHOWN FOR ILLUSTRATIVE PURPOSES ONLY. REFER TO APPROPRIATE DRYVIT SYSTEM LITERATURE FOR SYSTEM INSTALLATION.

2. EXPANSION JOINT IS NECESSARY WHERE SIGNIFICANT DIFFERENTIAL MOVEMENT IS EXPECTED AT FLOOR LINES

3. LOCATE EXTERNAL SEALANT JOINT WITHIN 1" (25 MM) OF BREAK IN SUBSTRATE.

4. FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.

5. DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.

6. IF OPTIONAL DRAINAGE TRACK IS USED, BACK OF EPS WILL NEED TO BE NOTCHED TO ACCOMMODATE THE DRAINAGE MEDIUM AND WATER-RESISTIVE BARRIER.

The architecture, engineering, and design of the project using the Dryvit products is the responsibility of the project's design professional. All systems must comply with local building codes and standards. This detail is for general information and guidance only and Dryvit specifically disclaims any liability for the use of this detail and for the architecture, design, engineering or workmanship of any project. The project design professional determines, in its sole discretion, whether this detail or a functionally equivalent detail is best suited for the project. Use of a functionally equivalent detail does not violate Dryvit's warranty. This detail is subject to change without notice. Contact Dryvit to ensure you have the most recent version.

